


FIRST ESTABLISH IF BRACELET IS 1, 2 OR 3 BELOW AND THEN PROCEED AS INDICATED

1. SLIDING CLASP


i) Insert fine tipped tool into hole in clasp.



ii) To open/close clasp clip, move the tool in the direction indicated.



iii) slide clasp along bracelet to desired position.




iv) When in selected position, locate tabs on the back of clasp into slots on the bracelet and snap down/close the clip [see procedure (ii)].

IMPORTANT

To avoid straining the clip do not use excessive pressure. If resistance is found when closing clip, the tabs are not located properly and should be re-located.

2. ADJUSTABLE CLASP

To set the bracelet to the required length, depress the end pin of the spring bar as indicated below using a pointed instrument (e.g. a pin) and relocate the spring bar in any one of the holes.



SPRING BAR

IF THE LENGTH REQUIRES FURTHER ADJUSTMENT FOLLOW PROCEDURE (i).

3. LINK ADJUSTMENT

Some of our bracelet models are now fitted with a multiple clasp system which is designed to make bracelet adjustment easier for you.

To reduce the size of the bracelet simply open and remove the adjustable clasp indicated as (A) on the diagram.



Some adjustable clasps can be finely adjusted by opening the clasp and re-locating into suitable clasp slot.

Note: Adjustable clasps will vary in style depending on the watch bracelet design.

Should you feel that your bracelet is too long or too short, the following procedure should be adopted.

(i) Complete your name and address overleaf and send with your watch direct by registered post to Service Department, T.P. (UK) Ltd, Alexander House, Chartwell Drive, Wigston, Leicester LE18 2EZ where it will receive immediate attention. This service is free of charge. Please do not send presentation box as this will not be returned.

(ii) Alternatively, if purchased from a High Street jewellers shop, take this gauge with your watch to that retailer for bracelet adjustment.

CUSTOMER'S NAME

ADDRESS

POSTCODE

DAYTIME PHONE NO


GL01/09-12

Limit

SINCE 1912

**BRACELET
GAUGE**

GL01



1. Place gauge around wrist.
2. Adjust to comfortable length on wrist.
3. Mark tape at required length.

DO NOT ATTEMPT TO ADJUST THE BRACELET YOURSELF BEYOND THE INSTRUCTIONS IN ITEMS 1, 2 AND 3 OVERLEAF. ANY DAMAGE CAUSED TO THE BRACELET WILL INVALIDATE THE MANUFACTURER'S GUARANTEE.