

LIMIT

1912

RACING
USER MANUAL

5391.56

5392.56

5393.56

5394.56

5395.56

RACING FUNCTIONS



EL BACKLIGHT



100M W/R



CHIME



DUAL TIME



STOPWATCH



BATTERY
(CR2025)



CALENDAR



ALARM

BUTTONS

- Button operation is indicated using the letters shown in the diagram below:



ATTENTION

1. Never try to open the case or remove its back cover.
2. Do not operate buttons underwater.
3. Should moisture appear inside the watch, have it checked immediately by your dealer. Otherwise it can cause erosion of the metal parts of the watch.
4. Though the watch is designed to withstand normal use, you should avoid rough use or dropping the watch.
5. Avoid exposing the watch to temperature extremes.
6. Wipe the watch with a dry, soft cloth only. Avoid allowing it to come into direct contact with chemical materials, which can cause deterioration of the plastic parts of the watch.
7. Avoid wearing the watch in electromagnetic and static conditions.

DISPLAY



BACKLIGHT

- The backlight uses an EL (electro-luminescent) which makes the display glow for easy reading in the dark.
- In the timekeeping mode, press "C" to illuminate the display for approx 3 secs.



MODE SELECTION

- Press "B" to change mode to mode in the following sequence:
Timekeeping Mode → Alarm Mode → Stopwatch Mode → Dual Time Mode

A) TIMEKEEPING

- 12/24hr Format.
- Hour, minutes, seconds, day of week, date.
- 100 years calendar (2000 - 2099).



B) ALARM

- Hourly time signal.
- The alarm sounds at the preset time each day.



C) STOPWATCH

- 1/100 second unit.
- Measuring range:
0'00"00 - 23:59'59"



D) DUAL TIME

- The time for another time zone.



A) TIMEKEEPING

12/24HR FORMAT

- In the timekeeping mode, press "A" to switch between 12/24hr formats.



CALENDAR

- In the timekeeping mode, press and hold "D" to display:
Year, month, date.



TIME SETTING

1. In the timekeeping mode, press and hold "A" and the seconds flash (indicating set mode activated).



2. Press "D" to reset the seconds.



3. Press "B" to change to next selection.



4. Press "D" to increase the number, press and hold to change at high speed.



5. Repeat steps 3 and 4 in the following sequence: Seconds → Hours → Minutes → Year → Month → Date

6. Press "A" to exit the set state, once complete (the day of the week is auto displayed in accordance with the year, month and date setting).

B) ALARM

- The alarm sounds at the preset time each day for about 60 seconds, press any button to stop it.

ALARM AND CHIME

- In the alarm mode, press "D" to on/off the alarm and chime in the following sequence:
Alarm and chime off → Alarm on →
Chime on → Alarm and chime on.



ALARM TIME SETTING

1. In the alarm mode, press "A" and the hour will flash (indicating set mode activated).



2. Press "D" to increase the hour, press and hold to increase at high speed.



3. Press "B" to select the minutes.



4. Press "D" to increase the minutes, press and hold to increase at high speed.



5. Press "A" to exit the set state, once complete.

C) STOPWATCH

LAP TIME

1. In the stopwatch mode, press "D" to start the stopwatch.



2. Press "D" again to stop the stopwatch.



3. Press "A" to reset the stopwatch.



TIME SETTING

1. In the stopwatch mode, press "D" to start the stopwatch.



2. Press "A" to display the split time, stopwatch timing continues internally.



3. Press "A" to clear the split time and continue time measurement.




4. Repeat steps 2 and 3 to measure the multi split time.
5. Press "D" to stop the stopwatch.


D) DUAL TIME

DUAL TIME SETTING


1. In the dual time mode, press "A" and the hour will flash (indicating set mode activated).




2. Press "D" to increase the hour, press and hold to increase at high speed.



3. Press "B" to select the minutes.



4. Press "D" to change the minutes (press once to change 30 minutes).



5. Press "A" to exit the set state, once complete.